

Pos.	Qty	Part number	Description	F/C	Pos.	Qty	Part number	Description	F/C
1	1	1 605 108 151	Motor Housing	71	111	1	3 600 917 042	Needle Bearing	56
2	1	1 614 220 105	Field 115V	22	112	1	2 917 530 199	Wrist Pin	47
3	1	1 604 010 185	Armature w/Fan 115V	AW	114	1	3 603 070 002	Plunger	52
3/5	1	2 606 610 049	Fan	23	116	1	2 912 080 238	Set Screw	85
4	1	1 607 200 086	Switch On/Off	15	117	1	3 601 006 010	Gasket	79
4/1	2	2 910 091 047	Screw	89	119	1	3 600 400 018	Guide Sleeve	82
5	1	3 604 460 555	Cord 115V 18/2	11	120	1	2 917 510 094	Pin	66
6	1	2 600 703 032	Strain Relief	11	121	1	3 603 301 016	Round Nut	85
7	1	1 601 302 017	Cord Clamp	89	122	1	3 607 031 358	Die Support	82
13	1	1 600 900 024	Ball Bearing	60	123	2	2 910 145 163	Screw	89
14	1	2 600 905 021	Ball Bearing	61	125	1	3 602 380 009	Guide Plate	92
16	2	1 601 323 019	Brush Holder	25	126	2	2 916 011 011	Washer	65
17	1	2 610 907 043	Label "1533A"	9	127	2	2 916 069 089	Spring Washer	65
17/5	1	2 610 906 874	Label "Caution"	9	128	2	2 910 141 160	Screw	89
18	1	1 604 611 026	Switch Spring	27	130	2	2 600 910 006	Needle Bearing	56
22	1	1 602 319 002	Switch Slide	9	131	2	1 600 100 631	Shim 0.5mm	65
23	1	1 602 026 057	Switch Button	9	132	1	3 605 805 026	Intermediate Plate	38
25	1	3 600 508 025	Motor Housing Cover	70	133	4	2 910 141 172	Screw	99
26	1	1 600 502 020	Rubber Bearing Sleeve	82	136	1	3 601 181 039	Guide Plate	92
29	1	1 601 328 005	Air Deflector	24	137	1	1 600 290 016	Oil Seal	77
39	2	1 604 652 013	Brush Spring	27	138	1	3 600 361 002	Bushing	82
40	4	1 604 477 011	Terminal	10	150	2	1 900 452 012	Terminal Sleeve	11
47	1	2 910 611 018	Screw	89	715	1	2 608 639 025	Punch	94
48	4	2 910 611 405	Screw	89	724	1	2 608 639 026	Die	94
53	1	1 604 448 005	Cable 95mm	10	750	1	2 602 025 075	Auxiliary Handle	9
54	1	1 604 448 006	Cable 40mm	10	751	1	2 607 001 190	Handle Extension Assy.	9
55	5	2 910 611 021	Screw	89			w/pos. 751/2, 751/3		
101	1	3 605 806 176	Gear Housing	72	751/2	1	2 916 011 022	Washer	65
102	1	3 606 110 007	Eccentric Shaft	53	751/3	1	2 603 450 009	Bolt	89
103	1	1 900 905 326	Ball Bearing	51	753	1	1 907 950 005	Allen Wrench 4mm	9
106	1	3 606 316 086	Eccentric Gear	34	808	1	1 601 106 999	Nameplate	9
108	1	3 600 917 019	Needle Bearing	56	810	1	3 604 321 019	Brush Set	26
109	1	3 600 200 041	Spacer	82	829	1	3 606 328 017	Intermediate Gear	31
110	1	3 602 001 006	Connecting Rod	57					

SERVICE NOTES: