

Pos.	Qty	Part number	Description	F/C	Pos.	Qty	Part number	Description	F/C
2	1	3 606 316 080	Eccentric Gear	34	125	1	3 600 508 025	Motor Housing Cover	70
3	1	2 916 640 006	Retaining Ring	89	126	1	1 600 502 020	Rubber Bearing Sleeve	82
4	1	3 606 316 081	Pinion Gear	33	129	1	1 601 328 005	Air Deflector	24
5	1	3 606 316 079	Intermediate Gear	31	139	2	1 604 652 013	Brush Spring	27
6	1	1 900 900 232	Ball Bearing	56	147	1	2 910 611 018	Screw	89
7	1	3 605 700 118	Intermediate Plate	38	148	4	2 910 611 405	Screw	89
8	1	3 601 015 020	Gasket	79	149	1	2 910 611 021	Screw	89
9	1	2 600 400 008	Bushing	82	150	2	1 900 452 012	Terminal Sleeve	10
10	1	2 600 500 002	Washer	65	151	4	1 604 477 011	Terminal	10
11	1	1 610 905 021	Ball Bearing	61	152	2	1 601 008 003	Insulating Plate	9
12	1	2 916 669 008	Retaining Ring	89	153	1	1 604 448 005	Cable 95mm	10
13	1	2 600 108 077	Felt	77	154	1	1 604 448 006	Cable 40mm	10
14	4	2 910 211 222	Screw	89	202	1	3 609 201 325	Retaining Ring	89
15	2	2 910 371 166	Screw	89	203	1	3 609 201 326	Ball Bearing	51
16	1	3 602 300 009	Key	66	205	1	3 609 201 327	Eccentric Shaft	53
17	1	2 917 571 094	Pin	66	206	1	3 609 201 328	Needle Bearing	56
101	1	1 605 108 151	Motor Housing	71	207	1	3 609 201 329	Retaining Ring	89
102	1	2 604 220 428	Field 115V	22	208	1	3 609 201 330	Ball Bearing	51
103	1	1 614 010 066	Armature w/Fan 115V	AW	209	1	3 609 201 331	Needle Bearing	56
103/€	1	2 606 610 049	Fan	23	210	1	3 609 201 332	Gear Housing	72
104	1	1 607 200 086	Switch On/Off	15	213	1	3 609 201 334	Wrist Pin	47
104/1	1	2 910 091 047	Screw	89	214	1	3 609 201 335	Connecting Rod	57
105	1	3 604 460 555	Cord 115V 18/2	11	217	1	3 609 201 338	Guide Plate	87
106	1	2 600 703 013	Strain Relief	11	218	4	2 912 771 120	Screw	89
107	1	1 601 302 017	Cord Clamp	89	220	1	3 609 201 341	Guide Plate	87
108	1	1 601 106 999	Nameplate	9	222	1	3 609 201 343	Set Screw	85
109	1	2 610 907 096	Label "1534"	9	223	1	3 609 202 322	Support	52
113	1	1 600 900 024	Ball Bearing	60	226	1	3 600 210 099	O-Ring	78
116	2	2 601 323 021	Brush Holder	25	+ 650	1	1 907 950 005	Allen Wrench 4mm	9
117	1	2 610 906 874	Label "Caution"	9	+ 651	1	3 607 950 008	Torx Wrench T-20	9
118	1	1 604 611 026	Switch Spring	27	715	1	2 608 639 024	Punch	94
122	1	1 602 319 002	Switch Slide	9	721	1	2 608 639 023	Die	94
123	1	1 602 026 057	Swtch Button	9	810	1	1 607 014 128	Brush Set	26

SERVICE NOTES: